



## Stopping and Towing Tips for Trucks Equipped with Volvo I-Shift, Mack M-Drive, Eaton Fuller, PACCAR & Detroit DT12 Transmissions

### Stopping


When parking the vehicle, always apply the parking brake and move the gear lever to the "N" position on the gear selector. Make sure the parking brake is holding the vehicle before leaving the drive position. Failure to do so can result in unexpected vehicle movement and can cause serious personal injury or death.

#### When the vehicle is stopped:

1. Apply the parking brake
2. Move the gear lever to the "N" position on the gear selector
3. Switch the engine to off

#### WHEN STOPPED!

ALWAYS PLACE THE VEHICLES IN N – NEUTRAL  
DO NOT LEAVE THE VEHICLE IN D – DRIVE WITH PARKING BRAKE APPLIED



### Towing

**CAUTION:** You must tow a vehicle equipped with a Volvo I-Shift or Mack M-Drive transmission according to the guidelines below. Failure to do so can result in damage to transmission components.

When towing the vehicle, the output shaft of the transmission must not be allowed to spin or turn. If the vehicle is towed with the drive wheels still in contact with the road surface, the vehicle axles shafts or driveline must be removed or disconnected.

**Note:** Always follow proper manufacturer towing procedures. Failure to follow proper towing procedures could result in damage to the transmission.



### Starting the Vehicle on a Hill

**DANGER:** The vehicle can roll when stopped on a hill or grade, or when the vehicle is starting from a stop on a hill or grade. Always use the brakes to hold the vehicle stationary on a hill or grade. Failure to do so can result in personal injury or death.

**CAUTION:** Always use the brakes to hold the vehicle stationary on an uphill stop. Never hold the vehicle stationary on an uphill slope using the accelerator pedal. The clutch could overheat, which could cause it to breakdown.

Edmonton  
Alberta  
833.442.0442

Mount Pearl  
Newfoundland  
844.442.0442

Moncton  
New Brunswick  
844.442.0442

Quebec City  
Quebec  
844.442.0442

Ottawa  
Ontario  
613.749.4858

Mississauga  
Ontario  
833.442.0442

Winnipeg  
Manitoba  
833.442.0442