











# Stopping and Towing Tips for Trucks Equipped with Volvo I-Shift, Mack M-Drive, Eaton Fuller, PACCAR & Detroit DT12 Transmissions

## Stopping

When parking the vehicle, always apply the parking brake and move the gear lever to the "N" position on the gear selector. Make sure the parking brake is holding the vehicle before leaving the drive position. Failure to do so can result in unexpected vehicle movement and can cause serious personal injury or death.

#### When the vehicle is stopped:

- 1. Apply the parking brake
- 2. Move the gear lever to the "N" position on the gear selector
- 3. Switch the engine to off

#### **WHEN STOPPED!**

ALWAYS PLACE THE VEHCILES IN N - NEUTRAL DO NOT LEAVE THE VEHCILE IN D - DRIVE WITH PARKING BRAKE APPLIED





### Towing

**CAUTION:** You must tow a vehicle equipped with a Volvo I-Shift or Mack M-Drive transmission according to the guidelines below. Failure to do so can result in damage to transmission components.

When towing the vehicle, the output shaft of the transmission must not be allowed to spin or turn. If the vehicle is towed with the drive wheels still in contact with the road surface, the vehicle axles shafts or driveline must be removed or disconnected.

**Note:** Always follow proper manufacturer towing procedures. Failure to follow proper towing procedures could result in damage to the transmission.



### **Starting the Vehicle on a Hill**

**DANGER:** The vehicle can roll when stopped on a hill or grade, or when the vehicle is starting from a stop on a hill or grade. Always use the brakes to hold the vehicle stationary on a hill or grade. Failure to do so can result in personal injury or death.

**CAUTION:** Always use the brakes to hold the vehicle stationary on an uphill stop. Never hold the vehicle stationary on an uphill slope using the accelerator pedal. The clutch could overheat, which could cause it to breakdown.

Edmonton
Alberta
833.442.0442

Mount Pearl Newfoundland 844.442.0442 Moncton New Brunswick 844.442.0442 Quebec City Quebec 844.442.0442

Ottawa Ontario 613.749.4858 Mississauga Ontario 833.442.0442

Winnipeg Manitoba 833.442.0442

WE ARE YOUR ONE-STOP DRIVELINE SOURCE SOLUTION!

**ULTPOWERTRAIN.COM**